

Zigbee Blinds Actuator Mini

Art. no.: 57008000



Operating instructions

1 Safety instructions

To avoid possible damage, read and follow the following instructions:



Installation only by persons with appropriate knowledge and experience in the following areas:

- 5 safety regulations and standards for the installation of electrical systems
- Selection of suitable tools, measuring devices, installation materials and, if necessary, personal protective equipment
- Installation of the installation material
- Connection of devices to the building installation under consideration of local connection conditions

Improper installation endangers your own life and the lives of users of the electrical system and there is a risk of serious damage to property, e.g. through fire. You are at risk of personal liability for personal injury and damage to property.

Contact an electrical contractor!

Risk of injury. Use the device only for controlling Venetian blind and roller shutter motors or awnings. Do not use it to switch other loads.

For parallel connection of several motors to an output it is essential to observe the corresponding instructions of the manufacturers, and to use a cut-off relay if necessary. The motors may be destroyed.

Use only venetian blind motors with mechanical or electronic limit switches. Check the limit switches for correct adjustment. Observe the specifications of the motor manufacturers. Device can be damaged.

Read the instructions in full, observe them and keep them for future reference.

2 Device components




Figure 1

- (1) Venetian blind actuator
- (2) Button **Prog.**
- (3) LED
- (4) Terminals

3 Intended use

- Zigbee actuator for controlling electrically driven Venetian blinds, shutters and awnings
- Zigbee transmitter to operate Zigbee-compliant Venetian blind drives

- Operation of Zigbee-compliant transmitters or connected Venetian blind push-buttons
- Mounting in appliance box according to DIN 49073 with a suitable cover

4 Product characteristics

- Zigbee Certified Product
- Positioning of the blind/shutter and slat
- Switchable output with **Prog.** button
- Blind/shutter running time and slat change-over time can be saved
- Input to connect a Venetian blind push-button
- Parameterising via app
- Updating via app

5 Operation

Operation with connected Venetian blind push-button

Moving the blind/shutter

- Press top or bottom button for longer than one second.
The blind/shutter moves in the desired direction to the end position or stops when the button is pressed again.

Adjusting the slats

- Press top or bottom button for less than 1 second.

Transmitter function

Additional Zigbee devices for controlling blinds/shutters can be connected to the actuator. This function is set with the NEXENTRO Config app. The devices are then operated in the same way as the actuator when a push-button is pressed.

Radio operation

The operation is done with Zigbee transmitters or Zigbee gateways that comply with Zigbee Standard 3.0. The scope of functions and the type of operation depends on the transmitter or gateway used.

6 Fitting and electrical connection

To ensure good transmission quality, keep a sufficient distance from any possible sources of interference, e.g. metallic surfaces, baby monitors, microwave ovens, WiFi routers and wireless headphones.



DANGER!

Electrical shock when live parts are touched.

Electrical shocks can be fatal.

Before carrying out work on the device or load, disengage all the corresponding circuit breakers, secure against being switched on again and check that there is no voltage!

-
-  Recommendation: Use an appliance box with an installation depth of 60 mm.




Figure 2: Connection diagram

(5) Venetian blind push-button




Figure 3: Clampable conductor cross-section

- Make the connection according to the connection diagram (Figure 2). In doing so, note the clampable conductor cross-section (Figure 3).
- Insert the actuator in the appliance box in such a way that the **Prog.** button and status LED are visible.
- i The load can be switched by briefly pressing the **Prog.** button.
 Press the **Prog** button for less than 1 second: Blind moves in the bottom end position direction.
 Press the **Prog** button for longer than 1 second: Blind moves in the upper end position direction.
- Mount a suitable cover or Venetian blind push-button.
- Perform commissioning.

7 Commissioning with app

The requirement for commissioning via app is a mobile end device (smartphone, tablet) with Bluetooth interface, running the Android or iOS operating system. The app guides you step by step through the commissioning process.

- i Prerequisite for scenes and positioning movements is that the moving times of the connected blind/shutter in the actuator are saved.
- Download and install the NEXENTRO Config app from the iTunes App Store (iOS) or Google Play Store (Android).

App functions

- Joining an existing network

- Setting up your own network
- Assigning device names
- Setting device parameters: Blind/shutter running time, slat adjusting time, pause time for direction change
- Reverse function of inputs and outputs
- Connecting the actuator with Zigbee transmitters, actuators or gateways
- Indication of the position and of the slat angle
- Indication of device information: Device type, software version
- Performing a software update
- Resetting to default setting
- Operating the actuator for test purposes

Registering new devices in the NEXENTRO Config app

NEXENTRO devices must be registered for commissioning in the NEXENTRO Config App. To do this, the new unit must be put into pairing mode, which is active for approx. 1 minute after mains voltage recovery.

- Re-energise the NEXENTRO device and start the search in the NEXENTRO Config App.
- Add the new device to the list of registered devices.
- Assigning device names (optional).

i With a registered device, connecting to a terminal is possible at any time.

Adding the NEXENTRO actuator to a Zigbee network with gateway

To connect the NEXENTRO actuator to other Zigbee devices, the NEXENTRO actuator must be added to the network.

i With certain gateways, adding to a network is done via the **Touchlink** function, see <http://www.nexentro.de/help>.

- Start the search mode for new devices in the app of the gateway to open the network for further Zigbee devices. The function call depends on the gateway, e.g. "Search devices".
- Select function **Join Network** in the NEXENTRO Config App.
The actuator joins the Zigbee network and is displayed in the app of the gateway.
The NEXENTRO Config App shows all available devices that can be controlled via the sensor function of the actuator.
- Select the devices.

Create a Zigbee network with the NEXENTRO actuator (without gateway)

A Zigbee network can be created with a NEXENTRO actuator and other NEXENTRO devices can be added to the network. Adding additional Zigbee devices is always done via the NEXENTRO device with which the Zigbee network was created.

- Select function **Create Network** in the NEXENTRO Config App.
- For NEXENTRO devices to join the network, select **Join Network**.
The NEXENTRO actuator has created a Zigbee network. The device search starts and searches for devices to join the network.
All available Zigbee devices are shown.
- Select the devices.

Adding the NEXENTRO actuator to a Zigbee network of NEXENTRO devices

The NEXENTRO actuator can be added to a network created with another NEXENTRO device via the function **Create Network**.

- Carry out the device search in the NEXENTRO Config App for the NEXENTRO device with which the Zigbee network was created.
- Switch to the NEXENTRO actuator to be added to the Zigbee network.
- Select the **Join Network** function.

The actuator joins the Zigbee network.

All available devices that can be controlled via the sensor function of the actuator are shown.

- Select the devices.

Joining a Zigbee network with a NEXENTRO actuator via Touchlink

Requirement: The distance between the Zigbee transmitter and the NEXENTRO actuator is 10 to 20 cm.


- Select function **Touchlink** in the NEXENTRO Config App.
The NEXENTRO actuator is ready to join the Zigbee network.
- Trigger Touchlink on the Zigbee transmitter.
The actuator joins the Zigbee network and is connected to the transmitter.
The NEXENTRO Config App shows all available devices that can be controlled via the sensor function of the actuator.
- Select the devices.

8 Commissioning without app

A simplified commissioning can also be carried out without the app.

Prerequisite: The actuator is in the default setting or the assignment to a Zigbee network has been deleted.

- Open the network of the gateway, see gateway app.
- Switch on mains voltage.
The actuator searches for the gateway's Zigbee network for 1 minute.
The blind/shutter is activated briefly in both running directions, the actuator has found the network and joined it. The actuator is displayed in the app of the gateway.
- If the actuator is operated without a gateway, connect the actuator to a transmitter via Touchlink within 5 minutes after switching on the mains voltage.

 A more detailed configuration can only be carried out with the NEXENTRO Config App.




DANGER!

Mortal danger of electric shock.

The following work must be carried out under mains voltage and therefore may only be carried out by an electrician!

Only use insulated tools for the work! Cover up live parts in the working environment.

Saving blind/shutter running time

-  Prerequisite for scenes and positioning movements is that the moving times of the connected blind/shutter in the actuator are saved.
- Press the **Prog.** button for longer than 1 second; release the button when the blind/shutter starts moving.
Blind/shutter moves in the upper end position direction.
- As soon as the upper end position is reached, press the **Prog.** button for longer than 4 seconds; release the button when the blind/shutter starts moving.
The blind/shutter moves in the bottom end position direction. The LED flashes green.
- When the bottom end position is reached, press the **Prog.** button again.
The LED flashes red.

- **With shutters:** Press the **Prog.** button for less than 1 second.
The running time is saved and the blind/shutter moves to the upper end position.
- **With Venetian blinds:** Press the **Prog** button for longer than 1 second and keep it pressed until the slats have been fully changed over, then release the button.
The running time and change-over time is saved and the blind/shutter moves to the upper end position.

9 Reset device

Deleting assignment to a Zigbee network

- Switch off the supply supply to the device three times in quick succession and switch it on again. The pause between switching operations must be less than two seconds.
The actuator confirms the deletion of the network assignment by briefly activating the blind/shutter in both running directions.

Resetting the device to the factory setting

The device deletes the assignment to a network, all connections to Zigbee devices and the parameters saved on the device. Alternatively, the device can also be reset with the NEXENTRO Config app.



DANGER!

Mortal danger of electric shock.

The following work must be carried out under mains voltage and therefore may only be carried out by an electrician!

Only use insulated tools for the work! Cover up live parts in the working environment.

Precondition: Load is switched off.

- Press the **Prog** button (2) for longer than 20 seconds.
The blind/shutter moves in the upper end position direction.
After approx. 20 seconds, the LED flashes rapidly alternately red and green.
 - Within 10 seconds, release the button and press it again briefly.
The LED flashes more slowly alternately red and green, the device is reset to the default settings and is restarted.
- i** After resetting the device to the default setting, the device has to be removed from the NEXENTRO Config App. For iOS devices, the device also has to be removed from the list of paired Bluetooth devices (Settings/Bluetooth). Otherwise, re-pairing will not be possible.

10 Technical data

Rated voltage	AC 230 / 240 V ~
Mains frequency	50 / 60 Hz
Standby power	max. 0.2 W
Running time	1 ... 120 s
Ambient temperature	-5 ... +45 °C
Storage/transport temperature	-25 ... +70 °C
Dimensions L×W×H	approx. 48 x 51 x 20 mm
Connected load	
Motors	700 W

Cable length inputs	max. 3 m
Zigbee	
Communication protocol	Zigbee 3.0 (router)
Radio frequency	2.400 ... 2,483 GHz
Transmission capacity	1 mW
Bluetooth	
Radio frequency	2.402 ... 2.480 GHz
Transmission capacity	max. 2.5 mW, Class 2
Transmitting range	typ. 10 m

11 Declaration of conformity

Insta GmbH hereby declares that the radio system type art. no. 57008000 meets the directive 2014/53/EU. You can find the full article number on the device. The complete text of the EU Declaration of Conformity is available under the Internet address:
www.insta.de/instastorefront/services/downloads

12 Warranty

We reserve the right to make technical and formal changes to the product in the interest of technical progress.

We provide a warranty as provided for by law.

Please send the unit postage-free with a description of the defect to our central customer service office:

Insta GmbH
Service Center
Hohe Steinert 10
58509 Lüdenscheid
Germany

Insta GmbH
Postfach 1830
58468 Lüdenscheid
Germany

Telefon +49 (0) 2351 936-0

www.insta.de
info@insta.de